
Wall Washer W+CW 2in1 LED Light



USER MANUAL

Please read manual carefully before use

CONTENTS

1. Safety Instructions	2
2. Technical Specification	5
3. DMX Set Up	6
4. Display	7
5. Menu	8
6. LUX Data	10
7. DMX Channel List	10
8. Mounting	12
9. Product Size	13
10. Attention	14
11. Trouble Shooting	14
A. The unit does not work, no light and the fan does not work	14
B. Not responding to DMX controller	14
C. One of the channels is not working well	15
12. Fixture Cleaning	15

Thank you for choosing our LED lights. Each facility has been rigorously tested. Please check whether the facility has been damaged during transportation. If you find any parts are missing or broken, please contact the manufacturer immediately. Please do not return the product without any notice!

1.Safety Instructions




Please read this manual carefully, which includes important information on installation, use and maintenance.

Attention

- Please keep this USER MANUAL for future consultation. If you sell the facility to another user, be sure that they also receive this USER MANUAL.
- Please open and check in details and make sure there is no transportation damage.
- Before operating, ensure that the voltage and frequency of power supply match the power requirements of the facility.
- It's important to ground the yellow/green conductor to earth in order to avoid electric shock.
- The facility must be installed in a location with adequate ventilation, at least
 50 cm from adjacent surfaces. Be sure that no ventilation slots are blocked.
- Make sure the power is disconnected before removing the facility.
- Make sure there are no flammable materials close to the unit while operating as it is fire hazard.
- Use safety cable when fixes this facility. Do not handle the facility by taking its head only, but always by taking its base.
- \bullet Maximum ambient temperature is 40 $^\circ\! C$. Do not operate it where the temperature is higher than this.
- Please stop using the facility for serious operating problems. Stop using the facility immediately. Never try to repair the facility by yourself, but be a professional technician. Please contact the supplier's service department for technical support.
- Do not touch any wire during operation as high voltage might be causing

- electric shock.
- When the housing or lens is damaged, it must be replaced.
- Direct sunlight or any other strong light source penetrating the lens of the light will cause serious internal damage to the facility. During unpacking, installation, use and long-term outdoor idleness, it is forbidden to expose the lens of the facility to direct sunlight or any other strong light source at any angle. It is forbidden to aim the beam of one light directly at another light.



Caution

There are no accessories available, do not open the housing and try to repair the facilities yourself. Please contact our company for after service.

Installation

The unit should be mounted via its screw holes on the bracket. Always ensure that the unit is firmly fixed to avoid vibration and slipping while operating. And make sure that the structure to which you are attaching the unit is secure and is able to support a weight of 10 times of the unit's weight. Also always use a safety cable that can hold 12 times of the weight of the unit when installing the fixture.


The facility must be installed by professionals, and keep it far away from fire, walking road, and easy touched place.


2. Technical Specification

Light Source	32*60W 2in1 LED(warm white+cool white)
LED Lifetime	≥ 50000H
Power Voltage	AC100-240V , 50-60Hz
Power Consumption	1050W
Beam Angle	38°
Control Modes	DMX512/ Auto/ Sound/ Master/ Manual/ RDM
DMX Channel	6/ 9 Channel
Protection Rating	IP65
Display	TFT Display
Data In/Out Socket	3-pin XLR sockets
Power Socket	Power-Con in/ out
Housing Material	Aluminum
Pan	540°accuracy 2.11°/step, fine-tuning accuracy: 0.008°

Tilt	270°accuracy 0.86°/step, fine-tuning accuracy: 0.0034°		
Pan/Tilt Resolution	Automatically correct pan/tilt position		
MAX. Connection	4 units (240V, 50Hz) 2.5mm² power cable		
WAX. Connection	2 units (100V, 60Hz) 2.5mm² power cable		
Dimension	514mm*222mm*324mm		
Net Weight	15.15 kg		
Carton Package	620mm*430mm*345mm 1in1 GW.: 20 kg		
Flight Case	790mm*670mm*530mm 3in1 GW.: 73.2 kg		
Features	Full optical domain dimming, with 65536 level dimming accuracy; Fast strobe 1-25Hz; Preset multiple color macro effect; Dimmer: 0~100% smooth dimming.		
	Signal cable 1pc		
Configuration	Power cable 1pc		
	Manual 1pc		

3. DMX Set Up





XLR Pin Configuration
pin 1=Ground
pin 2=Data Compliment (negative)
pin 3=Data true (positive)

Pin1: Ground pin2: Negative pin3: Positive

DMX Connection

To ensure optimal transmission of DMX data, please connect facilities in the shortest way. The connection order won't affect the DMX address code. For example, if the address code is set to 1, no matter where the facility is connected, its address code will not change. This is determined by the principle of the DMX controller.


Operation method

You can operate in the following three modes:


- Auto mode the light can automatically complete all color changes
- DMX control mode each light can be individually controlled by a standard
 DMX512 console
- Master mode any light can work as a host in any of the above modes, and the other lights will work synchronously as slaves

4. Display

There are four buttons on the LED panel: MENU, UP, DOWN, and ENTER.



Please press the "MENU" to exit or return to the previous menu, press "UP" or "DOWN" to select the upper and lower menus or adjust the values, and press "ENTER" to confirm.



After powering on, the facility will automatically return to the last operation when it was powered off, then get into standby status. For more details, please refer to the information below.

5. Menu


1-MENU 2-UP 3-DOWN 4-ENTER				
Menu	1.Mic Sense	001-100	Sound control adjust sensitiveness	
	2.Language	1.English	Select Display Language	
	Z.Language	2.Chinese		

	3.No Signal	1.Black Out 2.Hold	
	4.Fan Set	1.Auto 2.Low 3.High	
	5.Default	1.Yes 2.No	Factory setting
	6.Adjust	Pass Word: **** 1.Red: 0-255 2.Greed: 0-255 3.Blue: 0-255 4.White: 0-255	Changing the value of Pure white /Warm White can adjust the white balance, but the value can't be set to zero
Address	001-512		Setting the address from 001-512
Rever	2.Display	1.YES 2.NO	
	1.CH Value		Shown all channel information
Inform	2.Tem**℃		Show the temperature of LED board
	3.Soft V**		Program version number
	1.DMX512		
	2.Auto	1.Master	Sotting control mode
	3.Sound	1.Master	Setting control mode
	3.Souriu	2.Alone	
Mode			1.Red: 0-255
			2.Greed: 0-255
	4.Manual	1.Master 2.Alone	3.Blue: 0-255
		2.Alone	4.White: 0-255
			5.Strobe1: 0-255
	1.6Channels	6CH	
Channel	1.001141111013	0011	Select channel mode

6. LUX Data

CW+WW





7. DMX Channel List

► 6CH Mode

СН	Function	DMX Value	Description
1	Dimming	0 -255	Linear dimming from dark to bright
		0 -3	No function
2	Strobe	4 -203	Synchronous strobe speed slow to fast (1Hz-25Hz)
	204 -255		Random strobe
3	Pure White	0 -255	Linear dimming from dark to bright
4	Warm White	0 -255	Linear dimming from dark to bright
5	Linear Color	0-4	No function
	Temperature	5-255	Color temperature from

СН	Function	DMX Value	Description
			warm to cool
	Dimming Model	0-49	Model -1
		50-99	Model -2
6		100-149	Model -3
		150-255	Model -4


▶9CH Mode

СН	Function	DMX Value	Description
1	Pure White	0 -255	Linear dimming from dark to bright
2	Pure White adjustment	0 -255	Linear dimming from dark to bright
3	Warm White	0 -255	Linear dimming from dark to bright
4	Warm White adjustment	0 -255	Linear dimming from dark to bright
5	Dimming	0 -255	Linear dimming from dark to bright
6	Dimming adjustment	0 -255	Linear dimming from dark to bright
		0 -3	No function
7	Strobe	4 -203	Synchronous strobe speed slow to fast (1Hz-25Hz)
		204 -255	Random strobe
8	Linear Color	0-4	No function
	Temperature	5-255	Color temperature from warm to cool
9	Dimming Model	0 -49	Model -1
		50 -99	Model -2
		100 -149	Model -3
		150 -255	Model -4

8. Mounting

When installing the unit, the trussing or area of installation must be able to hold 10 times the weight without any deformation. When installing the unit must be secured with a secondary safety attachment, e.g. an appropriate safety cable. Never stand directly under the facility while mounting, uninstalling or repairing facilities.

High-altitude mounting requires for extensive experience, including working load limits calculating, installation material, and periodic safety check of installation materials and facilities. If you're lack of mentioned qualifications, do not attempt the installation yourself. These installation should be checked by a skilled person annually.




3240W-G2 works properly in above different mounting, hanging upside-down from a ceiling, sideways on trussing, or set on smooth horizontal surface. Be sure this facility is at least 12m (40ft) away from flammable materials (decoration etc.). Always use and install the safety cable to prevent accidental

damage or injury from the facility failure. Never use handles for secondary attachment.

NOTICE: The suitable environment temperature of the facility is from -25° C to 45° C. Do not place this facility in an environment where the temperatures are under or above the temperatures stated. This will help the fixture run at its best and extend the lifetime.

9. Product Size



10. Attention

- 1. When the facility is powered on, please avoid looking directly at the facility.
- 2. When assembling/ replacing LED, be sure to cut off the main power of facilities before opening the cover upon the LED board.

11. Trouble Shooting

Following are a few common problems that may occur during operation. Here are some suggestions for easy troubleshooting:

A. The unit does not work, no light and the fan does not work

- 1. Check the status of power connection and fuse.
- 2. Check the voltage.
- 3. Check the power indicator.

B. No response to DMX controller

- 1. If the display screen flashes, check the DMX signal connector and signal line whether the connection is correct.
- 1. If the display screen does not flash, but no response to channel control, check whether the address code or channel setting is correct.
- 1. If the DMX signal transmission is intermittent, check if the XLR and DMX cables are in good condition.
- 2. Try using another controller.
- 3. Check if the DMX cables is too close to the high-voltage wire, which may damage or interfere with the signal circuit.
- 6. The facility has not completed the self-check.

C. One of the channels is not working well

- The stepper motor might be damaged or the cable connected to the PCB is broken.
- 2. The motor's drive IC on the PCB might be out of condition.

12. Fixture Cleaning

The lens and diffuser should be clean frequently to get better light effect. Wipe frequency according to the environment. Humidity, excessive smoke, and dirty environment will make lens dusty.

- Use soft cloth and special glass cleaner.
- Wipe lens surface at least every 30 days.
- Use vacuum cleaners or air guns to clean the interior structure of the facility, at least twice a year.

Marning:

To avoid the danger of lighting strikes and fire, please do not place the facility in a humid environment. Do not disassemble it without permission, otherwise, the manufacturer will not provide warranty. If the facility fails, please contact the manufacturer first.

Product Warranty Card

Product: Wall Washer W+CW 2in1 LED Light

Model NO.:3240W-G2 Manufacture Date:

User: Purchase Date:

Manufacturer: Sales Store:

Address: ATTN: Phone:

Phone:

Note: The above blank must be filled in and sealed by the end user or sales point, otherwise no warranty will be provided. (Below please check the warranty period and terms)

Warranty Period: This facility is warranted for 2 years from the date of purchase.

Warranty Terms:

- 1. Except for man-made damage and natural disasters
- 2. If the facility fails to function properly during the warranty period, please contact our after service department or our local distributor directly.
- 1) Fail to present a valid warranty card.
- 2) Omissions, alterations, and trade sales names on the warranty card.
- 3) Failures and damage caused by force majeure.
- 4) Failures and damage caused during transportation and handling.
- 5) Failures and damage caused by failure to follow the instructions for use.
- 6) Failures and damage caused by disassembly, repair, and modification of the product without the manufacturer's authorization or by non-professionals.
- 7) Failures caused by the use of accessories not approved by the factory or not matched by the factory.

A	Thank you for	reading this	manual. Plea	ase keep it fo	or future refe	rence